



SEE TEMPLATE ON BACK FOR HOLE LOCATIONS

- A** Using template provided locate mounting holes in cabinet floor. Pre-drill holes with 1/8" drill bit, and install universal mounting plate (#34-91-4101) with four #8 x 3/4" Phillips head wood screws (#F0812-28-2). Repeat step one to install universal mounting plate to top of cabinet.
- B** Insert wheel hub assembly (#3470-07) into shelves (female keyways in wheel hub must align with male keys in hub of shelf). This is a taper fit, so tap lightly with heel of hand to sit hub into shelf.
- C** Insert shaft through the bottom of the lower shelf, slide shelf support (#34-77-4101) onto shaft with positioner grooves up, insert shaft through the bottom of the upper shelf.
- D** Insert shaft assembly with shelves into bottom mounting plate (be sure notch in shaft engages over key inside hole of mounting plate).
- E** Loosen upper shaft by twisting counter clockwise just enough so that shaft will slide up and down (about 1/2 turn). Holding down on bottom shaft with one hand, extend upper shaft and engage over center pin in upper mounting plate, twist clockwise until tight.
- F** Adjust upper shelf support positioner to desired height, rotate, and tighten set screw. Do this to make sure that the pie shape design of the tray is positioned properly in the 90 degree opening.

24", 28", & 32" Kidney Installation Template



NOTES (NOTA):

1. Be sure to check for adequate clearance at back of shelf prior to drilling holes
2. Template position may be adjusted for a full overlay door.
3. Any inside re-enforcement must be accounted for. (minimum dimensions noted)

SEE BACK FOR INSTRUCTIONS

