General Adjustment Instructions:

170° Hinge

- A Horizontal Side Adjustment Screw
- B Vertical Height Adjustment Screw
- C Depth Adjustment Screw (hinge must be opened to ~90° in order to access this screw)

105° Pie Corner Hinge

- D Horizontal Side Adjustment Screw
- E Vertical Height Adjustment Screw
- F Depth Adjustment Screw
- G Door Thickness Adjustment Screw (allows for various door thicknesses so no binding occurs)





