



Customer Use Sheet

Heavy Duty Ball Bearing Slides

21SLIDE SET HD, 24SLIDE SET HD

To Remove Drawer:

1. Open drawer to the fully extended position
2. Locate the black release triggers on each slide. One side trigger will pull up and the other side will pull down.
3. Simultaneously engage both release triggers; this will allow you to pull the drawer completely out of the cabinet.



To Reinstall Drawer:

1. Push the cabinet members of left and right slides back into the cabinet.
2. Align the drawer members with the cabinet members and slide the drawer into the cabinet opening.
3. At the halfway point, the black release triggers will engage. The drawer can now be fully closed or fully extended again.

